



PERRY ELECTRIC Srl
Via Milanese, 11
22070 VENIANO (Como) ITALY
www.perry.it

ENGLISH



Delay ON star/delta

1RT80S

1 mod. DIN



INFORMATION AND SAFETY PRECAUTIONS

It is advisable to read the installation and user instructions carefully and to keep them for future reference. The manufacturer reserves the right to make all the technical and construction changes it deems necessary without prior notice.

Important: the installation, electrical connection and commissioning of devices and equipment must be performed by qualified personnel and in compliance with regulations and applicable laws.

Before starting the installation and maintenance of the device, disconnect the 230V ~ mains power supply.


- Do not connect or power the unit if any part is visibly damaged.
- Once installation is complete, inaccessibility to the terminals without the use of special tools must be guaranteed.
- The manufacturer assumes no responsibility concerning the use of products that must comply with specific environmental and/or installation regulations.
- This unit must be intended only for the use for which it was built. Any other use must be considered improper and dangerous.

IMPORTANT


Device is constructed for connection in 1-phase AC/DC 12-240 V main alternating current voltage and must be installed according to norms valid in the state of application. Connection according to the details in this direction. Installation, connection, setting and servicing should be installed by qualified electrician staff only, who has learnt these instruction and functions of the device. This device contains protection against overvoltage peaks and disturbances in supply. For correct function of the protection of this device there must be suitable protections of higher degree (A, B, C) installed in front of them. According to standards elimination of disturbances must be ensured. Before installation the main switch must be in position "OFF" and the device should be de-energized. Don't install the device to sources of excessive electro-magnetic interference. By correct installation ensure ideal air circulation so in case of permanent operation and higher ambient temperature the maximal operating temperature of the device is not exceeded. For installation and setting use screw-driver cca 2 mm. The device is fully-electronic - installation should be carried out according to this fact. Nonproblematic function depends also on the way of transportation, storing and handling. In case of any signs of destruction, deformation, non-function or missing part, don't install and claim at your seller. After stop using the product it is possible to demount and recycle.

DISPOSING OF OLD ELECTRICAL AND ELECTRONIC EQUIPMENT
This symbol on the product or on its packaging indicates that this product cannot be treated as household waste. On the contrary, it must be taken to a specific collection centre for recycling electrical and electronic equipment, such as: - outlets, if a similar product to the one being disposed of is being purchased - local collection centres (waste collection centres, local recycling centres, etc.). By making sure the product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inadequate disposal of this product. Recycling materials will help conserve natural resources. For more detailed information about recycling this product, please contact the local office in your area, the household waste disposal service in your area or the shop where you purchased this product.

Description



Symbol





Connection

- a = Auxiliary voltage
- b = Switch for start
- c = Wiring of star/delta motor start

- S1 = contactor for motor supply voltage
- S2 = contactor (STAR)
- S3 = contactor (DELTA)

Un: AC/DC 12-240V / AC 50-60 Hz



Type of load	$\cos \varphi \geq 0.95$ AC1	AC2	AC3	AC5a	AC5a	HAL. 230V AC5b	AC6a	AC7b	AC12
mat. contacts AgNi, contact 16A	250V / 16A	250V / 5A	250V / 3A	250V / 3A (690VA)	X	800W	X	250V / 3A	250V / 10A
Type of load	AC13	AC14	AC15	DC1	DC3	DC5	DC12	DC13	DC14
mat. contacts AgNi, contact 16A	250V / 6A	250V / 6A	250V / 6A	24V / 16A	24V / 6A	24V / 4A	24V / 16A	24V / 2A	24V / 2A

Technical parameters

Power supply

Supply terminals	A1 - A2
Voltage range	AC/DC 12-240V AC 50-60Hz
Absorbed power	AC 0.7-3 VA DC 0.5-1.7 W
Max. dissipated power (Un + terminals)	4W
Operating range	-15% +10%
Supply indication	green LED

Function

Number of functions	1
Time scale	t1: 0.1s - 100gg t2: 0.1s - 1s
Time setting	rotary switch and potentiometer
Time deviation	5% - mechanical setting
Repeat accuracy	0.2 % - set value stability
Temperature coefficient	0.01% / °C (0.01% / °F)

Output

Number of contacts	2x changeover (AgNi contacts material)
Current rating	16A / AC1
Breaking capacity	4000VA / AC1, 384W / DC
Inrush current	30A / < 3s
Switching voltage	250V AC / 24V DC
Power dissipated (contacts)	max 1.2 W
Output indication	multifunction red LED
Mechanical life	10.000.000 cycles
Electrical life (resistive)	50.000 cycles
Recovery time	max. 150ms

Other information


Operating temperature	-20°C to +55°C (-4°F to 131°F)
Storage temperature	-30°C + +70°C (-22°F to 158°F)
Dielectric strength	4kV (between the power terminals and the output terminals)
Use	domestic / tertiary / industrial
Mounting/DIN rail	DIN rail EN 60715
Protection degree	IP40 from front panel / IP20 terminals
Overvoltage category	III
Pollution degree	2
Terminal wire max. capacity (mm²)	1 x 2.5 or 2 x 1.5 with sleeve 1 x 2.5
Dimensions (L x P x H)	17.6 x 64 x 90 mm
Weight	84 g
Standards	EN 61812-1

Characteristic

- Designated of delay On of motors star/delta.
- Time t1 (star):
 - time scale 0.1 s - 100 days - divided into 10 time ranges (0.1 s - 1 s - 10 s - 0.1 min - 1 min - 10 min - 0.1 h - 1 h - 10 hrs - 0.1 day - 1 day - 10 days - 30 days - 100 days)
 - rough time setting by rotary switch
- Time t2 (delay) between Δ / Δ :
 - time range 0.1 s - 1 s
 - fine time setting by potentiometer
- Supply voltage: AC 230 V, AC/DC 12-240V
- Output contact: 2 x changeover 16 A
- Output indication: multifunction red LED.
- 1-MODULE, DIN rail mounting.

Function

STAR/DELTA timer



More accurate setting of timing for long periods of time

Example of time setting to 8 hours period:

For rough setting use time scale 1-10s on the potentiometer.

For fine time setting aim for 8s on potentiometer, then recheck accuracy (using stopwatch etc).

On rough time setting, set potentiometer to originally desired scale 1-10 hours, leave a fine setting as it is.